BUY ON
www.cablematic.com

HUAEN NOTE COUNTER FOR H-3600 QUICK START QUIDE



1. Key introduction

RESTART: Used to start counting operation in the following cases. To resume counting after an error is cleared. To clear the displayed counted number. Press to start counting.

FUN: Press “FUN” key to shift UV/MG/IR function.

VALUE: Press “VALUE/+” to open value function. Under batch function, press “+” key can add batch no.

DEN:Press “DEN/-” to open sorter function. Under batch function, press “-” key can minus batch no.

VOICE:Press “VOICE” key to open voice and press again to close.

CUR:Press “CUR” to choose currency.

BATCH/ADD:Press “BATCH/ADD” key to show 100/50/20/10 & add.

2. Quick&Easy Operation

1. Voice： Press”VOICE” key key long time until machine show Y-01, call piece, then press “VALUE/+” to show Y-02 ,call piece and total amount or “DEN/-”key to show Y-00, the voice off .

2. Fake note counting: Press “VALUE/+” key long time until machine show U-01 , fake note counting , press “VALUE/+” or “DEN/-”key shot time to show U00 , fake note not counting.

3.UV setting:Press”BATCH/ADD”key long time until machine show A-05 , press “VALUE/+” or “DEN/-”key to shot time to change setting from from 0-10.

4.MG setting:Press”FUN”key long time until machine show b-05,press “VALUE/+” or “DEN/-”key to shot time to change setting from from 0-10.

BUY ON
www.cablematic.com

3. Factory setting

Press”FUN”key then powe on the machine show 9999999，factory setting success .

5.Error code

报警代码	报 警 原 因	自检代码	报 警 原 因
A	UV	FE1	Start sensor
b	MG	FE2	Left IR
C	Chain note	FE3	Right IR
D	Size	FE6	Clear
E	Double note	FE7	Disc code
F	Slope	FE9	Magnetic
H	Half note	FEA	UV light